


TAPA CABEZA COMPLETO


Modelos: GD168F / GD170F / GD178F / GD186FE



Nº	Código	4 HP 168	7 HP 178	9 HP 186	##
1	22KM	168F	178F	186F	02014
2	22KM	168F	178F	186F	02202
3	22KM	168F	178F	186F	02004
4	22KM	168F	178F	186F	02003
5	22KM	168F	178F	186F	02203
6	22KM	168F	178F	186F	02204
8	22KM	168F	178F	186F	02015
9	22KM	168F	178F	186F	02201
11	22KM	168F	178F	186F	02007
12	22KM	168F	178F	186F	02006
13	22KM	168F	178F	186F	02005
14	22KM	168F	178F	186F	02002
15	22KM	168F	178F	186F	02001
16	22KM	168F	178F	186F	02016
17	22KM	168F	178F	186F	02008
18	22KM	168F	178F	186F	02019
19	22KM	168F	178F	186F	02012
20	22KM	168F	178F	186F	02017
21	22KM	168F	178F	186F	02100
22	22KM	168F	178F	186F	02013
24	22KM	168F	178F	186F	02009
25	22KM	168F	178F	186F	02018
26	22KM	168F	178F	186F	02011

TAPA DE PUNTERÍAS

Modelos: GD168F / GD170F / GD178F / GD186FE



Nº	Código	4 HP 168	7 HP 178	9 HP 186	##
2	22KM	168F	178F	186F	03001
3	22KM	168F	178F	186F	03007
5	22KM	168F	178F	186F	03003
6	22KM	168F	178F	186F	01021
7	22KM	168F	178F	186F	03004
8	22KM	168F	178F	186F	03100
10	22KM	168F	178F	186F	03005