


CONTROL ACELERACIÓN COMPLETO


Modelos: GD168F / GD170F / GD178F / GD186FE



Nº	Código	4 HP 168	7 HP 178	9 HP 186	##
1	22KM	168F	178F	186F	11300
2	22KM	168F	178F	186F	11006
3	22KM	168F	178F	186F	11401
4	22KM	168F	178F	186F	11301
8	22KM	168F	178F	186F	11403
9	22KM	168F	178F	186F	11402
10	22KM	168F	178F	186F	11005
11	22KM	168F	178F	186F	11007
12	22KM	168F	178F	186F	11110
14	22KM	168F	178F	186F	11003
15	22KM	168F	178F	186F	11008
16	22KM	168F	178F	186F	11102
17	22KM	168F	178F	186F	11004
18	22KM	168F	178F	186F	11101

ARRANQUE COMPLETO

Modelos: GD168F / GD170F / GD178F / GD186FE



Nº	Código	4 HP 168	7 HP 178	9 HP 186	##
2	22KM	168F	178F	186F	14006
3	22KM	168F	178F	186F	14005
4	22KM	168F	178F	186F	14001
5	22KM	168F	178F	186F	14011
6	22KM	168F	178F	186F	14002
7	22KM	168F	178F	186F	14012
8	22KM	168F	178F	186F	14009
9	22KM	168F	178F	186F	14007
10	22KM	168F	178F	186F	14008
11	22KM	168F	178F	186F	14100