

Engranaje Intermedio BE628

No. Diagrama	Código	No. Referencia Metabo	Descripción
11	2000343359780	343359780	PIEZA DE APRIETE
13	2000631074000	631074000	EMPUÑADURA
16	2000316024070	316024070	CARCASA ENGRANAJE COMPLETO
18	2000339001290	339001290	ARANDELA DE TOPE
20	2000316022930	316022930	EJE CON EMBRAGUE
21	2000339210270	339210270	JUNTA
22	2000316022940	316022940	BRIDA DE ENGR. COMPLETO
30	2000141153400	141153400	ARANDELA
48	2000143192570	143192570	ANILLO "O"
54	2000343405980	343405980	INTERRUPTOR ELECTRÓNICO
55	2000141116970	141116970	TORNILLO ALOMADO
59	2000316025140	316025140	MANGUITO DE ASPIRACIÓN

