

Taladradora BDE 1100 00806000

No. Diagrama	Código	No. Referencia Metabo	Descripción
2	2000141118700	141118700	TORN.ALOM.PARA CHAPA
3	2000339210910	339210910	JUNTA
8	2000316032920	316032920	CARCASA
9	2000316032790	316032790	CARCASA
10	2000141160350	141160350	PASADOR CILÍNDRICO
12	2000143113860	143113860	RODAMIENTO RADIAL
13	2000141152150	141152150	ARANDELA
15	2000141154910	141154910	CHAVETA DE AJUSTE
18	2000339210850	339210850	JUNTA
21	2000316032800	316032800	CARCASA
31	2000343377080	343377080	EMPAÑADURA
37	2000314000790	314000790	MANGO COMPLETO
38	2000339150970	339150970	CHAPA GUIA AIRE
52	2000344494880	344494880	CORDÓN
58	2000143195080	143195080	"ANILLO"O

