

Taladro BHE 22

No. Diagrama	Código	No. Referencia Metabo	Descripción
6	2000316031900	316031900	CARCASA ENGRAN. COMPLETO
7	2000141153750	141153750	ARANDELA DE APOYO
9	2000340003310	340003310	EMPUJADOR
21	2000320050480	320050480	SUJETABOLAS
23	2000316032580	316032580	BRIDA
24	2000344070670	344070670	FIELTRO
26	2000343376750	343376750	PLOMO
28	2000339129610	339129610	ARANDELA
30	2000141154920	141154920	MUELLE DE PLATO
33	2000316031360	316031360	INTERRUPTOR COMPLETO
37	2000314000770	314000770	MANGO COMPLETO
38	2000343376040	343376040	ANILLO OBTURADOR
40	2000310007860	310007860	INDUCIDO CPL. 120 V
42	2000343374260	343374260	BRIDA
44	2000343374280	343374280	TAPA SIN ELECTRÓNICO
47	2000343393020	343393020	MANGO DE PISTOLA 2 PIEZAS
51	2000311009820	311009820	INDUCTOR CPL. 120 V
52	2000315012650	315012650	CARCASA DE MOTOR
56	2000316028100	316028100	SOPORTE ESCOBILLA
63	2000341012630	341012630	ANILLO

